

Capture USB DMX Box – Quick Start

- First make sure that the Capture software has been installed on the computer. This will allow automatic installation of Window drivers.
- Plug the Capture USB DMX Box into a USB port on your system.

Note: The Capture USB DMX Box is a "High-Power" USB device (drawing more than 100mA) and will only function properly when plugged into "High-Power" ports. USB ports on your computer and on USB hubs powered by an external supply are typically "High-Power". Ports on a "Self-Powered" hub, i.e. not powered by an external supply, are typically not "High-Power".

- Windows will automatically find drivers for the box and load them.
- Plug in all additional Capture USB DMX Boxes if you have more than one.
- Start Capture 3.0 and it will initialize the box and in the process flash all its LEDs for a few seconds.
- Open the "Providers" window (Tools / Providers) in Capture.
- Make sure the "Status" for "Capture DMX Boxes" is set to "Enabled". If not enable it by a right mouse button click on "Capture DMX Boxes" and select "Enable".
- Right click on the "Capture DMX Boxes" entry and select "Configure". This will display a list of all connected boxes.
- If you have several boxes, you can identify each box by right clicking on an entry and selecting "Identify". This will flash the LEDs of the corresponding box for a few seconds.
- For each port you want to use, make sure it is set to "Input" by right clicking on the port and selecting "Input" so that it's check mark is visible.
- Connect a DMX source. The "In" LED will flash to indicate DMX activity.

Note: The Capture USB USB DMX Box does not support remote setting of the DMX End-of-Line termination and the LEDs labeled "Term" do not reflect the actual status of this particular feature. Termination is normally enabled when the units are shipped from the factory. To disable or enable this feature, disconnect box, remove the 2 upper screws on each end-panel, and take the lid off. Each port has a jumper labeled "Termination". Move jumper to "On" or "Off" position to enable or disable termination for each port.

For additional information and support go to:

www.capturesweden.com

www.captureamericas.com

1/1